



IMPORTANT INFORMATION

Section 1C - General Information

**1
C**


Table of Contents

Table of Contents	1C-1	Propeller Removal/Installation	1C-13
Special Tools	1C-2	Standard Models	1C-13
Serial Number Location	1C-2	Power Trim System	1C-15
Conditions Affecting Performance	1C-3	General Information	1C-15
Weather	1C-3	Power Trim Operation	1C-15
Boat	1C-4	Trim Tab Adjustment	1C-17
Engine	1C-5	Compression Check	1C-18
Following Complete Submersion	1C-6	Cylinder Leakage Testing	1C-19
Powerhead Front View	1C-7	Analysis	1C-20
Powerhead Starboard View	1C-8	Water Pressure Measurement	1C-21
Powerhead Port View	1C-9	Painting Procedures	1C-22
Powerhead Top View	1C-10	Propeller	1C-22
Powerhead Aft View	1C-11	Gear Housing	1C-22
Propeller Selection	1C-12	Decal Application/Removal	1C-23




Special Tools

1. Compression Gauge MT26J (Snap-on) Adaptor MT26J300 (Snap-on).



2. Water Pressure Gauge 91-79250A2.



3. Adapter P/N 22-86306.




4. Connector P/N 22-89772.



Serial Number Location

The Outboard serial number is located on the lower starboard side of the engine block. A serial number is also located on the starboard side of the swivel bracket.




- a** - Serial Number
- b** - Model Year
- c** - Model Description

- d** - Year Manufactured
- e** - Certified Europe Insignia



Conditions Affecting Performance

Weather



It is a known fact that weather conditions exert a profound effect on power output of internal combustion engines. Therefore, established horsepower ratings refer to the power that the engine will produce at its rated rpm under a specific combination of weather conditions.

Corporations internationally have settled on adoption of I.S.O. (International Standards Organization) engine test standards, as set forth in I.S.O. 3046 standardizing the computation of horsepower from data obtained on the dynamometer. All values are corrected to the power that the engine will produce at sea level, at 30% relative humidity, at 77° F (25° C) temperature, and a barometric pressure of 29.61 inches of mercury.

Summer conditions of high temperature, low barometric pressure and high humidity all combine to reduce the engine power. This, in turn, is reflected in decreased boat speeds--as much as 2 or 3 miles-per-hour (3 or 5 Km per-hour) in some cases. (Refer to previous chart.) Nothing will regain this speed for the boater, but the coming of cool, dry weather.

In pointing out the practical consequences of weather effects, an engine--running on a hot, humid summer day--may encounter a loss of as much as 14% of the horsepower it would produce on a dry, brisk spring or fall day. The horsepower that any internal combustion engine produces, depends upon the density of the air that it consumes, and in turn, this density is dependent upon the temperature of the air, its barometric pressure and water vapor (or humidity) content.

Accompanying this weather-inspired loss of power is a second but more subtle loss. At rigging time in early spring, the engine was equipped with a propeller that allowed the engine to turn within its recommended rpm range at full throttle. With the coming of the summer weather and the consequent drop in available horsepower, this propeller will, in effect, become too large. Consequently, the engine operates at less than its recommended rpm.



Due to the horsepower/rpm characteristics of an engine, this will result in further loss of horsepower at the propeller, with another decrease in boat speed. This secondary loss, however, can be regained by switching to a smaller pitch propeller that allows the engine to again run at recommended rpm.

For boaters to realize optimum engine performance under changing weather conditions, it is essential that the engine have the proper propeller to allow it to operate at or near the top end of the recommended maximum rpm range, at wide-open-throttle, with a normal boat load.

Not only does this allow the engine to develop full power, but equally important is the fact that the engine also will be operating in an rpm range that discourages damaging detonation. This, of course, enhances overall reliability and durability of the engine.

Boat

WEIGHT DISTRIBUTION

1. Proper positioning of the weight inside the boat (persons and gear) has a significant effect on the boat's performance, for example:
 - a. Shifting weight to the rear (stern)
 - (1.) Generally increases top speed.
 - (2.) If in excess, can cause the boat to porpoise.
 - (3.) Can make the bow bounce excessively in choppy water.
 - (4.) Will increase the danger of the following - wave splashing into the boat when coming off plane.
 - b. Shifting weight to the front (bow)
 - (1.) Improves ease of planing off.
 - (2.) Generally improves rough water ride.
 - (3.) If excessive, can make the boat veer left and right (bow steer).

BOTTOM

For maximum speed, a boat bottom should be nearly a flat plane where it contacts the water and particularly straight and smooth in fore-and-aft direction.

1. **Hook:** Exists when bottom is concave in fore-and-aft direction when viewed from the side. When boat is planing, "hook" causes more lift on bottom near transom and allows bow to drop, thus greatly increasing wetted surface and reducing boat speed. "Hook" frequently is caused by supporting boat too far ahead of transom while hauling on a trailer or during storage.
2. **Rocker:** The reverse of hook and much less common. "Rocker" exists if bottom is convex in fore-and-aft direction when viewed from the side, and boat has strong tendency to porpoise.
3. **Surface Roughness:** Moss, barnacles, etc., on boat or corrosion of outboard's gear housing increase skin friction and cause speed loss. Clean surfaces when necessary.

WATER ABSORPTION

It is imperative that all through hull fasteners be coated with a quality marine sealer at time of installation. Water intrusion into the transom core and/or inner hull will result in additional boat weight (reduced boat performance), hull decay and eventual structural failure.



CAVITATION

Cavitation is caused by water vapor bubbles forming either from a sharp edge or angle on the gear case or from an irregularity in the propeller blade itself. These vapor bubbles flow back and collapse when striking the surface of the propeller blade resulting in the erosion of the propeller blade surface. If allowed to continue, eventual blade failure (breakage) will occur.

Engine

DETONATION

Detonation in a 4-cycle engine resembles the “pinging” heard in an automobile engine. It can be otherwise described as a tin-like “rattling” or “plinking” sound.


Detonation is an explosion of an unburned portion of the fuel/air charge after the spark plug has fired. Detonation creates severe shock waves in the engine, and these shock waves often find or create a weakness: The dome of a piston, cylinder head/gasket, piston rings or piston ring lands, piston pin and roller bearings.

A few of the most common causes of detonation in a marine 4-cycle application are as follows:

- Over-advanced ignition timing.
- Use of low octane gasoline.
- Propeller pitch too high (engine rpm below recommended maximum range).
- Lean fuel mixture at or near wide-open-throttle.
- Spark plugs (heat range too hot - incorrect reach - cross-firing).
- Inadequate engine cooling (deteriorated cooling system).
- Combustion chamber/piston deposits (result in higher compression ratio).

Detonation usually can be prevented if:

1. The engine is correctly set up.
2. Diligent maintenance is applied to combat the detonation causes.



51115

Damaged Piston Resulting from Detonation



Following Complete Submersion

SUBMERGED WHILE RUNNING (SPECIAL INSTRUCTIONS)

When an engine is submerged while running, the possibility of internal engine damage is greatly increased. If, after engine is recovered and with spark plugs removed, engine fails to turn over freely when turning flywheel, the possibility of internal damage (bent connecting rod and/or bent crankshaft) exists. If this is the case, the powerhead must be disassembled.

SALT WATER SUBMERSION (SPECIAL INSTRUCTIONS)


Due to the corrosive effect of salt water on internal engine components, complete disassembly is necessary before any attempt is made to start the engine.

FRESH WATER SUBMERSION (SPECIAL INSTRUCTIONS)

1. Recover engine as quickly as possible.
2. Remove cowling.
3. Flush exterior of outboard with fresh water to remove mud, weeds, etc. DO NOT attempt to start engine if sand has entered powerhead, as powerhead will be severely damaged. Disassemble powerhead if necessary to clean components.
4. Remove spark plugs and get as much water as possible out of powerhead. Most water can be eliminated by placing engine in a horizontal position (with spark plug holes down) and rotating flywheel.
5. Change engine oil and filter as outlined in **Section 1B “Changing Engine Oil”**. Run outboard for short time and check for presence of water in oil. If water present (milky appearance) drain and refill as previously mentioned.
6. Pour alcohol into carburetor throats (alcohol will absorb water). Again rotate flywheel.
7. Turn engine over and pour alcohol into spark plug openings and rotate flywheel.
8. Turn engine over (place spark plug openings down) and pour engine oil into throat of carburetors while rotating flywheel to distribute oil throughout crankcase.
9. Again turn engine over and pour approximately one teaspoon of engine oil into each spark plug opening. Again rotate flywheel to distribute oil in cylinders.
10. Remove and clean carburetors and fuel pump assembly.
11. Dry all wiring and electrical components using compressed air.
12. Disassemble the engine starter motor and dry the brush contacts, armature and other corrodible parts.
13. Reinstall spark plugs, carburetors and fuel pump.
14. Attempt to start engine, using a fresh fuel source. If engine starts, it should be run for at least one hour to eliminate any water in engine.
15. If engine fails to start, determine cause (fuel, electrical or mechanical). Engine should be run within 2 hours after recovery of outboard from water, or serious internal damage may occur. If unable to start engine in this period, disassemble engine and clean all parts. Apply oil as soon as possible.




Powerhead Front View



- a** - Air Box
- b** - Fuel Hose
- c** - Remote Control Harness Opening
- d** - Throttle Cable
- e** - Battery Cables
- f** - Shift Cable
- g** - Speedometer Hose
- h** - Remote Control and Engine Harness Connection
- i** - Voltage Regulator/Rectifier
- j** - ECM



Powerhead Starboard View




57882

9 Loctite PST Pipe Sealant (92-809822)

- a** - Flywheel Cover
- b** - Starter Motor
- c** - Battery Ground Cable
- d** - Oil Filter
- e** - Dipstick
- f** - 20 Amp Fuse
- g** - 30 Amp Fuse
- h** - Starter Relay
- i** - Trim Relay (2) 1 Hidden
- j** - Engine Harness Connector
- k** - Batter Positive Cable
- l** - Access Port, Water Pressure/ Temperature Sender Accessory
- m** - Water Temperature Sensor
- n** - Fuel Filter
- o** - Pressure Control Valve Housing
- p** - Ignition Coil Cylinders #2 & #3
- q** - Ignition Coil Cylinders #1 & #4



Powerhead Port View




58644

- a** - Enrichener (2)
- b** - Throttle Valve Adjustment Screw (3)
- c** - Intake Manifold Plug (4)
- d** - Dashpot
- e** - Shift Interrupt Switch
- f** - Throttle Position Sensor (TPS)



Powerhead Top View




57870

- a** - Camshaft Gear (2)
- b** - Timing Belt
- c** - Lifting Eye (2)
- d** - Flywheel
- e** - Timing Belt Tensioner
- f** - Thermostat Housing



Powerhead Aft View



- a** - Spark Plug Cover
- b** - Fuel Pump (2)
- c** - Oil Fill Cap



Propeller Selection

For in-depth information on marine propellers and boat performance - written by marine engineers - see your Authorized Dealer for the illustrated **“What You Should Know About Quicksilver Propellers... and Boat Performance Information”** (Part No. 90-86144).

For best all around performance from your outboard/boat combination, select a propeller that allows the engine to operate in the upper half of the recommended full throttle rpm range with the boat normally loaded (refer to Specifications). This rpm range allows for better acceleration while maintaining maximum boat speed.

If changing conditions cause the rpm to drop below the recommended range (such as warmer, more humid weather, operation at higher elevations, increased boat load or a dirty boat bottom/gear case) a propeller change or cleaning may be required to maintain performance and ensure the outboard’s durability.

Check full-throttle rpm using an accurate tachometer with the engine trimmed out to a balanced-steering condition (steering effort equal in both directions) without causing the propeller to “break loose”.

Refer to “Quicksilver Accessory Guide” for a complete list of available propellers.

1. Select a propeller that will allow the engine to operate at or near the top of the recommended full throttle rpm range (listed in **“Specifications,”** preceding) with a normal load. Maximum engine speed (rpm) for propeller selection exists when boat speed is maximum and trim is minimum for that speed. (High rpm, caused by an excessive trim angle, should not be used in determining correct propeller.) Normally, there is a 150-350 rpm change between propeller pitches.
2. If full throttle operation is below the recommended range, the propeller **MUST BE** changed to one with a lower pitch to prevent loss of performance and possible engine damage.
3. After initial propeller installation, the following common conditions may require that the propeller be changed to a lower pitch:
 - a. Warmer weather and great humidity will cause an rpm loss.
 - b. Operating in a higher elevation causes an rpm loss.
 - c. Operating with a damaged propeller or a dirty boat bottom or gear housing will cause an rpm loss.
 - d. Operation with an increased load (additional passengers, equipment, pulling skiers, etc.).




Propeller Removal/Installation

Standard Models


WARNING

If the propeller shaft is rotated while the engine is in gear, there is the possibility that the engine will crank over and start. To prevent this type of accidental engine starting and possible serious injury caused from being struck by a rotating propeller, always shift outboard to neutral position and remove spark plug leads when you are servicing the propeller.


1. Shift outboard to neutral position.



2. Remove the spark plug leads to prevent engine from starting.




3. Straighten the bent tabs on the tab washer.




a - Tab Washer



- Place a block of wood between gear case and propeller to hold propeller and remove propeller nut.




- Pull propeller straight off shaft. If propeller is seized to the shaft and cannot be removed, have the propeller removed by an authorized dealer.
- Coat the propeller shaft with Quicksilver Anti-Corrosion Grease or 2-4-C Marine Lubricant with Teflon.



2-4-C w/Teflon (92-850736A1)

IMPORTANT: To prevent the propeller hub from corroding and seizing to the propeller shaft, especially in salt water, always apply a coat of the recommended lubricant to the entire propeller shaft at the recommended maintenance intervals and also each time the propeller is removed.


- Flo-Torque I Drive Hub Propellers



- a - Thrust Washer
- b - Propeller
- c - Continuity Washer
- d - Thrust Hub
- e - Propeller Nut Retainer
- f - Propeller Nut




8. Flo-Torque II Drive Hub Propellers



- a - Forward Thrust Hub
- b - Replaceable Drive Sleeve
- c - Propeller
- d - Rear Thrust Hub
- e - Propeller Nut Retainer
- f - Propeller Nut

9. Place a block of wood between gear case and propeller, and torque propeller nut to 55 lb-ft (75 Nm), aligning flat sides of the propeller nut with tabs on the tab washer.

10. Secure propeller nut by bending three of the tabs into the thrust hub grooves.



- a - Thrust Hub Grooves
- b - Tabs

Propeller Nut Torque
55 lb-ft (75 Nm)

11. Reinstall spark plug leads.

Power Trim System

General Information

The power trim system is filled at the manufacturer and is ready for use.

Trim outboard through entire trim and tilt range several times to remove any air from the system.

The trim system is pressurized and is not externally vented.

Power Trim Operation

With most boats, operating around the middle of the “trim” range will give satisfactory results. However, to take full advantage of the trimming capability there may be times when you choose to trim your outboard all the way in or out. Along with an improvement in some performance aspects comes a greater responsibility for the operator, and this is being aware of some potential control hazards. The most significant control hazard is a pull or “torque” that can be felt on the steering wheel or tiller handle. This steering torque results from the outboard being trimmed so that the propeller shaft is not parallel to the water surface.



⚠ WARNING

Avoid possible serious injury or death. When the outboard is trimmed in or out beyond a neutral steering condition, a pull on the steering wheel or tiller handle in either direction may result. Failure to keep a continuous firm grip on the steering wheel or tiller handle when this condition exists can result in loss of boat control as the outboard can turn freely. The boat can now “spin out” or go into a very tight maximum turn which, if unexpected, can result in occupants being thrown within the boat or out of the boat.

Consider the following lists carefully:

TRIMMING IN OR DOWN CAN:

1. Lower the bow.
2. Result in quicker planing off, especially with a heavy load or a stern heavy boat.
3. Generally improve the ride in choppy water.
4. Increase steering torque or pull to the right (with the normal right hand rotation propeller).
5. In excess, lower the bow of some boats to a point where they begin to plow with their bow in the water while on plane. This can result in an unexpected turn in either direction called “bow steering” or “over steering” if any turn is attempted or if a significant wave is encountered.

⚠ WARNING

Avoid possible serious injury or death. Adjust outboard to an intermediate trim position as soon as boat is on plane to avoid possible ejection due to boat spin-out. Do not attempt to turn boat when on plane if outboard is trimmed extremely in or down and there is a pull on the steering wheel or tiller handle.

TRIMMING OUT OR UP CAN:

1. Lift the bow higher out of the water.
2. Generally increase top speed.
3. Increase clearance over submerged objects or a shallow bottom.
4. Increase steering torque or pull to the left at a normal installation height (with the normal right hand rotation propeller).
5. In excess, cause boat “porpoising” (bouncing) or propeller ventilation.
6. Cause engine overheating if any water intake holes are above the water line.

TRIM “IN” ANGLE ADJUSTMENT

Some outboard boats, particularly some bass boats, are built with a greater than normal transom angle which will allow the outboard to be trimmed further “in” or “under”. This greater trim “under” capability is desirable to improve acceleration, reduce the angle and time spent in a bow high boat, altitude during planing off, and in some cases, may be necessary to plane off a boat with aft live wells, given the variety of available propellers and height range of engine installations.

However, once on plane, the engine should be trimmed to a more intermediate position to avoid a bow-down planing condition called “plowing”. Plowing can cause “bow steering” or “over steering” and inefficiently consumes horsepower. In this condition, if attempting a turn or encountering a diagonal, moderate wake, a more abrupt turn than intended may result.




In rare circumstances, the owner may decide to limit the trim in. This can be accomplished by repositioning the tilt stop pins into whatever adjustment holes in the transom brackets is desired.

⚠ WARNING

Avoid possible serious injury or death. Adjust outboard to an intermediate trim position as soon as boat is on plane to avoid possible ejection due to boat spin-out. Do not attempt to turn boat when on plane if outboard is trimmed extremely in or down and there is a pull on the steering wheel or tiller handle.

If an adjustment is required, purchase a stainless steel tilt pin (P/N 17-49930A1) and insert it through whatever pin hole is desired. The non-stainless steel shipping bolt should not be used in this application other than on a temporary basis.



a - Optional Tilt Pin


Trim Tab Adjustment

Propeller steering torque will cause your boat to pull in one direction. This steering torque is a normal thing that results from your outboard not being trimmed so the propeller shaft is parallel to the water surface. The trim tab can help to compensate for this steering torque in many cases and can be adjusted within limits to reduce any unequal steering effort.

NOTE: Trim tab adjustment will have little effect reducing steering torque if the outboard is installed with the anti-ventilation plate approximately 2 inches (50mm) or more above the boat bottom.

Operate your boat at normal cruising speed, trimmed to desired position. Turn your boat left and right and note the direction the boat turns more easily.

If adjustment is necessary, loosen trim tab bolt and make small adjustments at a time. If the boat turns more easily to the left, move the trailing edge of trim tab to the left. If the boat turns more easily to the right move the trailing edge of trim tab to the right. Retighten bolt and retest.



a - Trim Tab



Compression Check


⚠ CAUTION

Before removing the spark plugs, use compressed air to blow away dirt accumulated in the spark plug well.

NOTE: Use Snap-on compression gauge with adaptor. P/N MT26J-MT26J300. Spark plug size is 14 mm.

IMPORTANT: Compression check should be done with throttle in WOT position.

1. Check valve clearance (refer to “Valve Clearance Adjustment” in section 4A), adjust if out of specification.
2. Warm up the engine.
3. Remove all spark plugs.
4. Lubricate threads in cylinder head and on compression gauge. Install compression gauge in spark plug hole.



110 4-Stroke Outboard Oil (92-828000A12)

- a** - Compression Gauge (MT26J - Snap-on)
- b** - Adaptor (MT26J300 - Snap-on)

5. Hold throttle plate at W.O.T.
6. Crank the engine over until the compression reading peaks on the gauge. Record the reading.
7. Check and record compression of each cylinder. The highest and lowest reading recorded should not differ by more than 15% (see example chart below). A reading below 120 psi might indicate a total engine wear problem.

Compression Pressure (Minimum)
135 psi (950 Kpa, 9.5 kg/cm ²)

Example of compression test differences:

Maximum (psi)	Minimum (psi)
180	162
150	127.5







8. Remove compression gauge.
9. Install spark plugs.

NOTE: Compression check is important because an engine with low or uneven compression cannot be tuned successfully to give peak performance. It is essential, therefore, that improper compression be corrected before proceeding with an engine tuneup.

Cylinder Leakage Testing

NOTE: Cylinder leakage testing*, along with compression testing, can help the mechanic pinpoint the source of a mechanical failure by gauging the amount of leakage in an engine cylinder. Refer to the manufactures tester instructions for proper testing procedures.

NOTE: Cylinders #1 and #4 TDC positions should show TDC mark on flywheel with timing marks (f). Cylinders #2 and #3 TDC positions should show TDC mark alone (g).



- a - TDC for Cylinder #1
- b - TDC for Cylinder #2
- c - TDC for Cylinder #3
- d - TDC for Cylinder #4
- e - Cylinder Leakage Tester (Snap-On-Tools MT324)
- f - Flywheel Position For Arrow Positions #1 & #4
- g - Flywheel Position For Arrow Positions #2 & #3

NOTE: Spark plug hole is a 14 mm diameter. Use Snap-On Tool MT26J300 adapter with valve core removed.



Analysis

Due to standard engine tolerances and engine wear, no cylinder will maintain a 0% of leakage. It is important only that cylinders have somewhat consistent reading between them. Differences of 15 to 30% indicate excessive leakage. Larger engines tend to have a larger percentage of cylinder leakage than smaller engines.

If excessive leakage is present, first check that the piston is at top dead center of its compression stroke. Leakage will naturally occur if the exhaust or intake valve is open.

To determine the cause of high percentage leaks, you must locate where the air is escaping from. Listen for air escaping thru the carburetor intake, adjacent spark plug holes, exhaust pipe, and crankcase fill plug. Use the following table to aid in locating the source of cylinder leakage:



Air Escaping From:	Indicates Possible Defective:
Carburetor	Intake Valve
Exhaust System	Exhaust Valve
Crankcase Fill Plug	Piston or Rings
Adjacent Cylinders	Head Gasket



Water Pressure Measurement


1. Warm up engine.
2. Remove plug.
3. Attach adaptor, hose fitting and water pressure gauge to cylinder block.

NOTE: Water pressure measurements should be done on a warm engine with thermostat operating 140°F (60°C).



a - Plug

Water Pump Pressure





Painting Procedures

⚠ WARNING

Avoid serious injury from flying debris. Avoid serious injury from airborne particles. Use eye and breathing protection with proper ventilation.

Propeller

1. Sand the entire area to be painted with 3M 120 Regalite Polycut or coarse Scotch-Brite, disc or belts.
2. Feather edges of all broken paint edges. Try not to sand through the primer.
3. Clean the surface to be painted using PPG Industries DX330 Wax and Grease Remover or equivalent (Xylene or M.E.K.).
4. If bare metal has been exposed, use Quicksilver's Light Gray Primer.
5. Allow a minimum of 1 hour dry time and no more than 1 week before applying the finish coat.
6. Apply the finish coat using Quicksilver's EDP Propeller Black.

Gear Housing

The following procedures should be used in refinishing gear housings. This procedure will provide the most durable paint system available in the field. The materials recommended are of high quality and approximate marine requirements. The following procedure will provide a repaint job that compares with a properly applied factory paint finish. It is recommended that the listed materials be purchased from a local Ditzler Automotive Finish Supply Outlet. The minimum package quantity of each material shown following is sufficient to refinish several gear housings.

Procedure:

1. Wash gear housing with a muriatic acid base cleaner to remove any type of marine growth, and rinse with water, if necessary.
2. Wash gear housing with soap and water, then rinse.
3. Sand blistered area with 3M 180 grit sandpaper or P180 Gold Film Disc to remove paint blisters only. Feather edge all broken paint edges.
4. Clean gear housing thoroughly with (DX-330) wax and grease remover.
5. Spot repair surfaces where bare metal is exposed with (DX-503) alodine treatment.

IMPORTANT: Do not use any type of aerosol spray paints as the paint will not properly adhere to the surface nor will the coating be sufficiently thick to resist future paint blistering.

6. Mix epoxy chromate primer (DP-40) with equal part catalyst (DP-401) per manufacturers instructions, allowing proper induction period for permeation of the epoxy primer and catalyst.
7. Allow a minimum of one hour drying time and no more than one week before top coating assemblies.
8. Use Ditzler Urethane DU9000 for Mercury Black, DU34334 for Mariner Grey, and DU35466 for Force Charcoal, and DU33414M for Sea Ray White. Catalyze all four colors with Ditzler DU5 catalyst mixed 1:1 ratio. Reduce with solvents per Ditzler label.

**⚠ CAUTION**

Be sure to comply with instructions on the label for ventilation and respirators. Using a spray gun, apply one half to one mil even film thickness. Let dry, flash off for five minutes and apply another even coat of one half to one mil film thickness. This urethane paint will dry to the touch in a matter of hours, but will remain sensitive to scratches and abrasions for a few days.

9. The type of spray gun used will determine the proper reduction ratio of the paint.

IMPORTANT: Do not paint sacrificial zinc trim tab or zinc anode.

10. Cut out a cardboard “plug” for trim tab pocket to keep paint off of mating surface to maintain good continuity circuitry between trim tab and gear housing.

Decal Application/Removal

DECAL REMOVAL

1. Mark decal location before removal to assure proper alignment of new decal.
2. Carefully soften decal and decal adhesive with a heat gun or heat blower while removing old decal.
3. Clean decal contact area with a 1:1 mixture of isopropyl alcohol and water.
4. Thoroughly dry decal contact area and check for a completely cleaned surface.

INSTRUCTIONS FOR “WET” APPLICATION

NOTE: The following decal installation instructions are provided for a “Wet” installation. **All** decals should be applied wet.

TOOLS REQUIRED

1. Plastic Squeegee*
2. Stick Pin
3. Dish Washing **Liquid/Detergent without ammonia**** “Joy” and “Drift” are known to be compatible for this process.

* Automotive Body Filler Squeegee

** Do not use a soap that contains petroleum based solvents.

SERVICE TIP: Placement of decals using the “Wet” application will allow time to position decal. Read entire installation instructions on this technique before proceeding.

TEMPERATURE

IMPORTANT: Installation of vinyl decals should not be attempted while in direct sunlight. Air and surface temperature should be between 60°F (15°C) and 100°F (38°C) for best application.

SURFACE PREPARATION

IMPORTANT: Do not use a soap or any petroleum based solvents to clean application surface.

Clean entire application surface with mild dish washing liquid and water. Rinse surface thoroughly with clean water.



DECAL APPLICATION

1. Mix $\frac{1}{2}$ ounce (16 ml) of dish washing liquid in one gallon (4 l) of cool water to use as wetting solution.

NOTE: Leave protective masking, if present, on the face of decal until final steps of decal installation. This will ensure that the vinyl decal keeps its shape during installation.

2. Place the decal face down on a clean work surface and remove the paper backing from “adhesive side” of decal.
3. Using a spray bottle, flood the entire “adhesive side” of the decal with the pre-mixed wetting solution.
4. Flood area where the decal will be positioned with wetting solution.
5. Position pre-wetted decal on wetted surface and slide into position.
6. Starting at the center of the decal, “**lightly**” squeegee out the air bubbles and wetting solution with overlapping strokes to the outer edge of the decal. Continue going over the decal surface until all wrinkles are gone and adhesive bonds to the cowl surface.
7. Wipe decal surface with soft paper towel or cloth.
8. **Wait 10 - 15 minutes.**
9. Starting at one corner, “carefully and slowly” pull the masking off the decal surface at a 180° angle.

NOTE: To remove any remaining bubbles, pierce the decal at one end of the bubble with stick pin and press out the entrapped air or wetting solution with your thumb (moving toward the puncture).