



Connect as below:

Serial Suite:

ECU Plug:

Red

to

1 Pins Red (Power Supply +12 Volt)

Black

to

2 Pins Black (Ground)

Green

to

1 Pin Green (K Line)

Yellow

to

1 Pin Yellow (Flash Voltage)